

# AIR CLEAN DEVISER TAIWAN

## SMALL AREA

### FFU Mini Group Control System

- LCD screen
  - The User can control and set FFU from the display screen.
  - Monitor the status (RPM, Operating, Failure, Alarm) of FFU in a single unit, as a group, or in a loop (all connected FFU).
  - Control the on/off and adjust air volume of FFU in a single unit, as a group, or in a loop (all connected FFU).
  - Can divide all connected FFU units into multiple groups.
  - Can check FFU alarm code.
  - Built-in buzzer for failure alarm.
  - Can connect to PC through RS485 communication interface and built-in standard Modbus RTU communication protocol.
- 2 sets of built-in signal output, can connect according to requirement (choose two out of three).
    - A. Differential pressure gauge abnormal signal
    - B. FMGC Power On
    - C. FFU abnormal signal
  - Differential pressure gauge sensor signal input (0~10V or 4~20mA).
  - Can add customized function (differential pressure display).
  - Can connect up to 255 units of FFU.
  - Can connect a maximum of 63 units of FMCG.

